



Download Flyer

# Viewer Utility LANTECH VIEW

No dedicated server is needed

## Virtual Machine with RESTful API

- Easily deploy on the Virtual Machine (VM) of VMWare, enhancing scalability and flexibility.
- Enhancing Performance with RESTful API Support

Batch Config

## Maintenance

- Import/Export Monitored Device's Configuration
- Batch Import/Export Multiple Device's Configuration
- Check/Upgrade the Latest Version of the Device Firmware
- Batch Upgrade Multiple Device's Firmware
- Export Monitored Device's SNAPSHOT Image
- Batch Export Multiple Devices' SNAPSHOT Images







Snapshots

Batch Firmware Upgrade

## Scheduling

- Auditing and Troubleshooting with History of Scheduled Actions
- Automating Routine Maintenance Tasks

Schedule Reboot/ Upgrade/ Backup



## Dashboard

- Simplifying Initial Setup with First-time Setup Wizard
- Elevating User Experience with a User-Friendly GUI and Dashboard
- Making Data Analysis Effortless with Easily Understandable Charts



## Logs & Events

- Prioritizing Issues with Categorized Severities of Logs

## Devices Management

- Streamlining Network Setup with Devices Auto-Discovery
- Enhancing Device Identification with Device LED Blinking
- Detailed Network Insights with Per Device Port RMON Status Monitoring

## Alerts

- Staying Informed with Support Notifications for Alerts/Warnings
- Customizing Alerts with User-Defined Events to be Notified

## Other Features



- Overcoming Language Barriers with Multiple Languages Support (Currently available: English and Japanese)



- Visualizing Network Topology with Live Topology (Optional)



- Ensuring Data Integrity with Cloud Backup and Firmware Upgrade (Optional)

## Supported Models

### Lantech Managed Switches

Layer 2  
Layer 3  
Layer 3 Lite

### OS platform

OS1/OS2/OS2Pro/OS3/OS4/OS5

## System Requirement

### Hardware Requirements

CPU: Quad-core CPU  
RAM: 8 GB or higher  
Hardware Disk Space: 100 GB SSD or higher  
Supported Hypervisors: VM Workstation 14 or above

### Software Requirements

Browser  
Chrome: Version 76 or above  
Firefox: Version 69 or above  
Microsoft Edge: Version 79 or above

### TAIWAN

Lantech Communications Global, Inc.  
7F, No.33, Sec.1, Tiding Blvd., Neihu Dist.,  
Taipei, Taiwan, 114066  
Tel: +886-2-2790-2589  
www.lantechcom.tw

### EUROPE

Lantech Communications Europe GmbH  
Philipp-Kachel-Str. 42a, 63911  
Klingenberg, Germany  
Tel: +49 9372-50959-97  
sales@lantechcom.eu  
www.lantechcom.eu

### NORTH AMERICA

Sales Representative  
Industrial Components & Engineering, LLC.  
26 Adirondack Rd., Bordentown, NJ 08505  
harry@ice-reps.com

### SOUTH AMERICA

claudio.silva@lantechcom.tw

### AUSTRALIA

Lantech Communications Australia Pty Ltd.  
Suite #11, 1044A Dandenong Road,  
Carnegie, VIC 3163  
Tel: +61-3-7036-0400  
sales@lantechcom.com.au  
www.lantechcom.com.au

### SINGAPORE

25 Bukit Batok Crescent  
#10-07 THE ELITIST  
Singapore 658066  
lim@lantechcom.tw

### UK

The Barracks Business Centre, Wakefield Road,  
Pontefract, West Yorkshire WF8 4HH  
Tel: +44 (0) 1977 877477  
ken.woolley@lantechcom.tw